ALTEC LANSING®

inMotion™

MOBILE AUDIO

iMX2

User's guide
Guía del usuario

The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

Caution: To prevent the risk of electric shock, do not remove cover (or back). No user- serviceable parts inside. Refer servicing to qualified service personnel.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Caution

To prevent electric shock do not use this (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

Warning

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

Connecting the Power Cord (AC Wall Socket)

Snap plug into power supply and then insert the blades into the outlet. The power supply may be plugged upside down with no effect on product. Please note, the inMotion iMX2 can also be powered with four AA batteries (not included).

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water — This apparatus shall not be exposed to dripping or splashing, and no objects filled with liquids, such as vases, shall be placed on the apparatus.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. The apparatus should not be situated on a bed, sofa, rug or similar surface that may block the ventilation openings. The apparatus must not be placed in a built-in installation, such as a closed bookcase or cabinet that may impede the flow of air through the ventilation openings. Ventilation should not be impeded by covering the openings with items such as newspapers, tablecloths, curtains, etc.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. No naked flame sources, such as lighted candles, should be placed on the apparatus.
10. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for the replacement of the obsolete outlet.
11. Protect the power cord from being walked on or pinched — particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
12. Do not install in an area which impedes the access to the power plug. Disconnecting the power plug is the only way to completely remove power to the product and must be readily accessible at all times.
13. Power source — Use only power supplies of the type specified in the operating instructions or as marked on the appliance. If a separate power supply is included with this apparatus, do not substitute with any other power supply — use only manufacturer-provided power supplies.
14. Unplug this apparatus during lightning storms or when unused for long periods of time.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. For service, refer to qualified service personnel, return to the dealer, or call the Altec Lansing service line for assistance.
16. For products which incorporate batteries, please refer to local regulations for proper battery disposal.

Altec Lansing Technologies, Inc. One Year Limited Warranty

What Does The Warranty Cover?: Altec Lansing warrants that its products shall be free from defects in materials or workmanship, with the exceptions stated below.

What Is The Period Of Coverage?: This warranty runs for one year from the date of purchase. The term of any warranties implied by law shall expire when your limited warranty expires. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

What Does The Warranty Not Cover?: This warranty does not cover any defect, malfunction or failure that occurs as a result of: improper installation; misuse or failure to follow the product directions; abuse; or use with improper, unintended or faulty equipment. (For information on proper installation, operation and use consult the manual supplied with the product. If you require a replacement manual, you may download a manual from **www.alteclansing.com**.) Also, consequential and incidental damages are not recoverable under this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

What Will Altec Lansing Do To Correct The Problem?: Altec Lansing will, at its option, repair or replace any product that proves to be defective in material or workmanship. If your product is no longer being manufactured, or is out of stock, at its option, Altec Lansing may replace your product with a similar or better Altec Lansing product.

How To Get Warranty Service: To get a covered product repaired or replaced, you must contact Altec Lansing during the warranty period by email (csupport@alteclansing.com). You must include in your email, your name, address, email address, telephone number, date of purchase and a complete description of the problem you are experiencing. In the United States, you may alternatively contact Altec Lansing by telephone at 1-800-ALTEC88 — please be prepared to provide the same information. If the problem appears to be related to a defect in material or workmanship, Altec Lansing will provide you a return authorization and instructions for return shipment. Return shipments shall be at the customer's expense, and the return must be accompanied by the original proof of purchase. You should insure the shipment as appropriate because you are responsible for the product until it arrives at Altec Lansing.

How Will State Law Affect Your Rights?: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

The above limited warranties and remedies are sole warranties and remedies available to purchaser, if, and to the extent, valid and enforceable under the applicable law.

Customer Service

The answers to most setup and performance questions can be found in the Troubleshooting guide. You can also consult the FAQs in the customer support section of our Web site at **www.alteclansing.com**. If you still can't find the information you need, please call our customer service team for assistance before returning the speakers to your retailer under their return policy.

Tel: 800-258-3288

Email: csupport@alteclansing.com

For the most up-to-date information, be sure to check our Web site at **www.alteclansing.com**.

inMotion iMX2 Mobile Audio Dock

Thank you for purchasing this Altec Lansing product. For generations, Altec Lansing has been first in audio innovation. Today, our line of powered speakers has received more performance awards than any other brand. In all kinds of desktop environments, in every price range, Altec Lansing offers sound of distinction — giving even the most demanding customers the audio enjoyment they seek. Just listen to this!

BOX CONTENTS

- inMotion iMX2 Mobile Audio Dock
- Home antenna cable adapter
- 3.5 mm stereo cable (for secondary input)
- Power supply
- Protective carry bag
- User's guide and quick connect instructions

COMPATIBLE XM2GO RECEIVERS:

Works with:

- Delphi MyFi XM2go receiver
- Pioneer Airware XM2go receiver
- Tao XM2go receiver

PLACING THE inMOTION iMX2

Position the inMotion iMX2 on a level surface, preferably close to you.

For live reception of XM satellite radio programing

Outdoor use

When outdoors, make sure your XM2go receiver and inMotion iMX2 mobile audio dock have an unobstructed view of the southern sky.

Note: If you are unable to receive any XM signals, we suggest you plug in the home antenna according to the indoor instructions below.

Indoor use

When indoors, connect the XM Radio home antenna that came with your XM2go receiver directly to the XM2go receiver (not to the inMotion iMX2 mobile audio dock), as follows:

- Locate the home antenna cable adapter included with the inMotion iMX2.
- Insert the home antenna cable adapter's 3.5mm cable into the XM2go receiver's headphone jack. This will de-activate the XM2go receiver's internal FM transmitter.
- Insert the XM Radio home antenna cable into the home antenna cable adapter's large input jack.
- Insert the home antenna cable adapter's smaller cable into your XM2go receiver's antenna jack.
- Make sure the XM Radio home antenna points south outdoors through a window.

ASSEMBLING THE inMOTION iMX2

Place the compatible XM2go receiver docking adapter onto the docking connector. Docking adapters are labeled for XM2go receiver identification.

POWER

Use one of the following two options to power your inMotion iMX2:

AC (WALL OUTLET) POWER

Insert the barrel connector from the power supply into the DC connector on the back of the inMotion iMX2. After this connection is made, insert the power supply into a wall outlet.

DC (BATTERY) POWER

Install four AA batteries (not included) into the battery compartments on the bottom of the inMotion iMX2 (two to each compartment). Make sure the batteries are installed as illustrated in the battery compartments.

START PLAYING

1. Place your XM2go receiver onto the docking connector.
2. Turn on your XM2go device.
3. Turn on the inMotion iMX2 by pushing the power button located on the top of the unit. A blue LED will light around the button when the power is on.

Note: To avoid hearing a popping sound when you turn on your inMotion iMX2, always turn on your audio source first.

POWER OFF

Turn off the inMotion iMX2 by pushing the power button located on the top of the unit. The LED will turn off.

AUTO SHUT-DOWN (STANDBY)

The inMotion iMX2 automatically shuts down (standby) if no audio is detected after three minutes. While this mode reduces battery consumption, it does not completely turn the inMotion iMX2 off. To maximize battery life when not using the inMotion iMX2, push the power button located on the top of the unit. The LED will turn off.

CONNECTING TO ALTERNATE AUDIO SOURCE

Connect an alternate audio source — such as a CD player, MP3 player, or portable DVD player — to your inMotion iMX2 by plugging one end of the lime-green audio input cable to the line out of your portable device (if it has one) or to the device's headphone jack. Connect the other end to the input marked "AUX" on the back of the inMotion iMX2.

VOLUME

The "+" and "–" buttons on the top of the inMotion iMX2 are the master volume controls. Press and hold the "+" button to increase the volume and the "–" button to decrease the volume.

FOR ADDITIONAL BASS

The inMotion iMX2 is equipped with a subwoofer jack ("SUB OUT"). This output should only be used to connect an Altec Lansing optional subwoofer specifically designed to increase the bass output of this speaker system. Please check **www.alteclansing.com** for availability information.

TROUBLESHOOTING

SYMPTOM	POSSIBLE PROBLEM	SOLUTION
Power LED is not lit (AC Operation).	The power supply isn't connected to a wall outlet and/or the power supply connector is not plugged into the DC connector on the back of the inMotion iMX2.	Insert the barrel connector from the power supply into the DC connector on the back of the inMotion iMX2. After this connection is made, insert the power supply into a wall outlet.
	The surge protector (if used) isn't powered on.	If the power supply is plugged into a surge protector, make sure the surge protector is switched on.
	The wall outlet is not functioning.	Plug another device into the same wall outlet to confirm the outlet is working.
	The power isn't turned on.	Turn on the inMotion iMX2 by pushing the power button located on the top of the unit. A blue LED will light around the button when the power is on.
Power LED is not lit (Battery Operation).	No batteries are installed.	Install four AA batteries (not included) into the battery compartments on the bottom of the inMotion iMX2 (two to each compartment). Make sure the batteries are installed as illustrated in the battery compartments.
	The power isn't turned on.	Turn on the inMotion iMX2 by pushing the power button located on the top of the unit. A blue LED will light around the button when the power is on.
No sound is coming from speakers.	The XM Radio home antenna (not included) is not getting a signal.	Make sure the antenna points south outdoors or through a window. Specific instructions and tips on how to improve signal reception can be found in your XM2go receiver user's guide.
	The volume is set too low.	The "+" and "–" buttons on the top of the inMotion iMX2 are the master volume controls. Press and hold the "+" button to increase the volume.
	The XM2go receiver is not correctly seated onto the docking connector.	Remove the XM2go receiver and re-seat it in the docking station.
	The XM2go receiver is properly docked and the inMotion iMX2's blue LED is lit, but the XM2go receiver is in the "mute" mode.	Turn off the "mute" function on the XM2go device by pressing the mute button on the receiver or your remote control.
	If using an alternate audio source, the audio source is not properly connected to the inMotion iMX2 or there is a problem with the alternate audio source.	Connect an alternate audio source — such as a CD player, MP3 player, or portable DVD player — to your inMotion iMX2 by plugging one end of the lime-green audio input cable to the line out of your portable device (if it has one) or to the device's headphone jack. Connect the other end to the input marked "AUX" on the back of the inMotion iMX2.
There is a crackling sound coming from speakers.	If using an alternate audio source, the audio source is not properly connected to the inMotion iMX2 or there is a problem with the alternate audio source.	Connect an alternate audio source — such as a CD player, MP3 player, or portable DVD player — to your inMotion iMX2 by plugging one end of the lime-green audio input cable to the line out of your portable device (if it has one) or to the device's headphone jack. Connect the other end to the input marked "AUX" on the back of the inMotion iMX2.
There is a crackling sound coming from speakers (when connected to PC or laptop).	The volume level in operating system is set too high.	Check the operating system volume level and decrease if necessary.
The sound is distorted.	The volume level on inMotion iMX2 is set too high.	The "+" and "–" buttons on the top of the inMotion iMX2 are the master volume controls. Press and hold the "–" button to decrease the volume.
There is radio interference.	The unit is too close to a radio tower.	Move your speakers to see if the interference goes away.

ALTEC LANSING®

inMotion™

MOBILE AUDIO

This Class B digital apparatus complies with Canadian ICES-003. • Cet appareillage digital de Classe B est conforme au ICES-003 canadien.

CORPORATE HEADQUARTERS 535 Rte. 6 & 209, Milford, PA 18337-0277, USA • 866-570-5702 • 570-296-4434 • Fax 570-296-6887

EUROPE 13 Rue Beaumont, L-1219 Luxembourg, Luxembourg • Tel: +352 26 15 76 36 • Fax: +352 26 15 76 26

ASIA/PACIFIC 25 Canton Road, Tsim Sha Tsui, Kowloon, Hong Kong • (852) 2735-7331 • Fax (852) 2730-7748

Engineered in USA. Made in China

A10847 R01